

List of components 1:4

1/1	Battery XC90	4/56	Central Electronic Module (CEM)
		4/58	Rear Electronic Module (REM)
2/14	Relay, glow plug unit, XC90	4/68	Steering Angle Sensor module (SAS), XC90
2/22	Relay, climate control system XC90	4/70	Upper Electronic Module (UEM)
2/32	Main relay, engine management system, XC90	4/71	Cooling fan control module, XC90
		4/78	Accessory Electronic Module (AEM), XC90
2/35	Relay, starter motor, XC90	4/82	Differential Electronic Module (DEM), XC90
2/64	Relay, auxiliary lights, XC90	4/83	Fuel pump control module, XC90
2/90	Relay, windshield wiper, low/high speed, XC90	4/86	Parking Assistance Module (PAM)
2/91	Relay, intermittent wiping, XC90	5/1	Driver Information Module (DIM), XC90
2/182	Relay, high pressure headlight washer motor, XC90		
		6/1	Windshield wiper motor, XC90
		6/25	Starter motor, XC90
3/1	Ignition switch, XC90	6/26	Alternator Control Module (ACM)
3/4	Cruise control switch unit (SWS), XC90	6/28	Motor, ventilation fan, XC90
3/9	Brake light contact, XC90	6/29	Motor, cooling fan, XC90
3/47	Parking brake contact, XC90	6/33	Fuel pump, XC90
3/60	Switch, auxiliary lights, XC90	6/35	Fuel pump, auxiliary heater, XC90
3/71	Gear selector contacts, 4T65AWD	6/44	Cooling fan, electronics box, engine compartment, XC90
3/95	Spin control switch, XC90		
3/111	Light Switch Module (LSM)	6/48	Damper Motor Module (DMM), recirculation
3/112	Climate Control Module (CCM)	6/62	Left-hand power door mirror
3/126	Driver/Passenger Door Module (DDM)/(PDM), XC90	6/63	Right-hand power door mirror
		6/67	Pump, fuel leakage control, XC90
3/127	Passenger/Driver Door Module (PDM)/(DDM), XC90	6/69	Damper Motor Module (DMM), ventilation/floor/defroster
3/155	Automatic transmission program selector	6/73	Coolant pump, auxiliary heater, XC90
3/156	Gear Selector Module (GSM)	6/95	Damper Motor Module (DMM), temperature, left-hand side
3/254	Steering Wheel Module (SWM)		
3/267	Telematics switch unit, XC90	6/96	Damper Motor Module (DMM), temperature, right-hand side
4/7	Combustion Preheater Module (CPM)	6/102	Damper Motor Module (DMM), defroster
4/9	Control module, Supplementary Restraint System (SRS)	6/103	Damper Motor Module (DMM), floor/ventilation
4/16	Brake Control Module (BCM), XC90	6/104	High pressure headlight washer, XC90
4/28	Transmission Control Module (TCM)	6/113	Coolant pump, 8-cyl.
4/28	Transmission Control Module (TCM), TF80-SC AWD	6/114	Vacuum pump, XC90
		6/120	Engine throttle body, XC90
4/31	Ventilation fan control module, XC90	6/120	Motor, throttle body, 8-cyl.
4/33	Sun Roof Module (SRM)	6/127	Washer motor, XC90
4/46	Engine Control Module (ECM), XC90		
4/46	Engine Control Module (ECM), 8-cyl.		
4/52	Power Seat Module (PSM), XC90		

List of components 2:4

7/4	Brake fluid level sensor, XC90	7/74	Automatic transmission fluid temperature sensor, 4T65AWD
7/5	Washer fluid level sensor, XC90	7/74	Fluid temperature sensor, automatic transmission, TF-80SC AWD
7/6	Oil pressure switch, XC90	7/81	Pressure sensor, intake pipe, 8-cyl.
7/8	Pressure sensor, climate control system, XC90	7/82	Heated oxygen sensor, diagnosis 1
7/8	Pressure sensor, climate control system, 8-cyl.	7/82	Front heated oxygen sensor, bank B, 8-cyl.
7/10	Interior temperature sensor, XC90	7/91	Steering angle sensor, XC90
7/11	Ambient temperature sensor, XC90	7/93	Occupant Weight Sensor (OWS)
7/12	Solar sensor, twilight sensor and alarm indicator, XC90	7/100	Inclination Sensor Module (ISM)
7/15	Heated oxygen sensor, XC90	7/103	Heated oxygen sensor 3, XC90
7/15	Front heated oxygen sensor, bank A, 8-cyl.	7/103	Rear heated oxygen sensor, bank A, 8-cyl.
7/16	Coolant temperature sensor, XC90	7/104	Rear heated oxygen sensor, bank B, 8-cyl.
7/16	Coolant temperature sensor, 8-cyl.	7/105	Ambient temperature sensor, engine control module, XC90
7/17	Mass airflow sensor (MAF), XC90	7/123	Clutch pedal sensor, XC90
7/17	Mass air flow sensor (MAF), 8-cyl.	7/124	Brake pedal sensor, XC90
7/23	Rear knock sensor, XC90	7/129	Brake pressure sensor 2, XC90
7/23	Knock sensor, bank B, 8-cyl.	7/139	Brake pressure sensor 1, XC90
7/24	Front knock sensor, XC90	7/149	Rain Sensor Module (RSM)
7/24	Knock sensor, bank A, 8-cyl.	7/156	Fuel pressure and temperature sensor, XC90
7/25	Impulse sensor, XC90	7/159	Air Quality Sensor (AQS)
7/25	Impulse sensor, Diesel, XC90	7/162	Pressure sensor, fuel lines, XC90
7/25	Impulse sensor, 8-cyl.	7/164	Body Sensor Cluster (BSC), XC90
7/31	Front left ABS sensor, XC90	7/165	Intake manifold pressure and temperature sensor, XC90
7/32	Front right ABS sensor, XC90	7/172	Camshaft position sensor, intake side, XC90
7/35	Oil level sensor, XC90	7/172	Intake camshaft position sensor, bank A, 8-cyl.
7/41	Evaporator temperature sensor, XC90	7/173	Camshaft position sensor, exhaust side, XC90
7/51	Accelerator pedal sensor, XC90	7/173	Camshaft position sensor, exhaust side, Diesel, XC90
7/56	Rear left ABS sensor, XC90	7/173	Exhaust camshaft position sensor, bank A, 8-cyl.
7/57	Rear right ABS sensor, XC90	7/173	Exhaust camshaft position sensor, bank A, 8-cyl.
7/61	Input rpm sensor, 4T65AWD	7/188	Intake camshaft position sensor, bank B, 8-cyl.
7/61	Input speed sensor, TF-80SC AWD	7/189	Exhaust camshaft position sensor, bank B, 8-cyl.
7/62	Output rpm sensor, 4T65AWD		
7/62	Output speed sensor, TF-80SC AWD		
7/73	Coolant level sensor, XC90		

List of components 3:4

8/3	Electromagnetic clutch, climate control system, XC90	8/107	Valve, variable intake, 8-cyl.
8/3	Electromagnetic clutch, climate control system, 8-cyl.	8/111	High pressure solenoid valve, Diesel, XC90
8/6-10	Injectors, Diesel, XC90	8/115-116	Injectors, 8-cyl.
8/6-11	Injectors, XC90	8/117	Solenoid, variable valve timing intake, bank B, 8-cyl.
8/6-11	Injectors, 8-cyl.	8/118	Solenoid, variable valve timing outlet, bank B, 8-cyl.
8/17	EGR valve, Diesel, XC90	8/142	Linear pressure solenoid SLB1 TF-80SC AWD
8/18	EVAP valve, XC90	8/143	Linear pressure solenoid SLC1 TF-80SC AWD
8/18	EVAP valve, 8-cyl.	8/144	Linear pressure solenoid SLC2 TF-80SC AWD
8/19	Variable valve timing solenoid, intake, XC90	8/145	Linear pressure solenoid SLC3 TF-80SC AWD
8/19	Solenoid, variable valve timing intake, bank A, 8-cyl.		
8/28	Turbo control valve, XC90	9/12	Seat Heater Module (SHM), left-hand
8/36	Shift lock solenoid, XC90	9/13	Seat Heater Module (SHM), right-hand
8/37	Automatic transmission, 4T65AWD	9/30	Auxiliary heater, XC90
8/37	Automatic transmission TF-80SC AWD	9/32	PTC resistor, air preheating, XC90
8/38	Shift solenoid 1, 4T65AWD	10/1	Front left lamp housing, XC90
8/38	Shift solenoid 1 TF-80SC AWD	10/2	Front right lamp housing, XC90
8/39	Shift solenoid 2, 4T65AWD	10/3	License plate lighting, XC90
8/39	Shift solenoid 2 TF-80SC AWD	10/11	Front left Position/parking lights, XC90
8/40	Lock-up solenoid, 4T65AWD	10/12	Front right Position/parking lights, XC90
8/40	Lock-up solenoid TF-80SC AWD	10/17	Rear right lamp housing, XC90
8/41	Pressure solenoid, 4T65AWD	10/18	Rear left lamp housing, XC90
8/46	DSTC activation unit, XC90	10/65	Front right auxiliary light, XC90
8/64	Solenoid valve, engine pad, Diesel XC90	10/69	Front left auxiliary light, XC90
8/71	Throttle solenoid TF-80SC AWD	10/71	Side running light, front left, XC90
8/78	Oil pressure sensor, 4T65AWD	10/73	Side running light, front right, XC90
8/81	Variable valve timing solenoid, outlet, XC90	11A	Main fuses in fuse box engine compartment XC90
8/81	Variable valve timing solenoid, outlet, bank A, 8-cyl.	11B	Fuses in engine compartment fuse box XC90
8/82	Variable turbo geometry solenoid, Diesel XC90	11C	Fuses in passenger compartment fuse box
8/84	Vacuum pump switch, XC90	11E	Main fuses at battery
8/85	Thermal switch and fuel filter heating, XC90		

List of components 4:4

15/31	Engine compartment electrical distribution box XC90	31/48	Ground connection, rear seat riser right side, XC90
16/1	Audio Module (AUM)	31/53	Ground connection, firewall, XC90
16/2	Amplifier, V70	31/66	Ground connection, front seat riser left side
16/5	Speaker, right rear door, V70	31/67	Ground connection, front seat riser right side
16/6	Speaker, left rear door, V70	31/70	Ground connection, left side member lower engine compartment, XC90
16/15	CD changer	31/72	Ground connection, cargo compartment
16/35	Siren Control Module (SCM)	31/73	Ground connection, rear seat riser right side, XC90
16/45	Road Traffic Information (RTI)	31/83	Ground connection, A-pillar left side, XC90
16/46	RTI display	31/84	Ground connection, A-pillar right side
16/46	Multimedia display, XC90	31/88	Ground connection, Engine ignition coil group 1
16/57	Speaker, left D-pillar, V70	31/88	Ground connection, engine ignition coils, 8-cyl.
16/58	Speaker, right D-pillar, V70	31/89	Ground connection, Engine ignition coil group 2
16/60	Phone Module (PHM), XC90	31/89	Ground connection, engine ignition coils, 8-cyl.
16/62	Hand unit, cellular telephone, XC90	31/90	Ground connection, engine ignition coils, 8-cyl.
16/79	Bass speaker, V70	31/93	Ground connection, left MacPherson strut tower, XC90
16/79	Subwoofer Module (SUB), XC90	31/94	Ground connection, right MacPherson strut tower, XC90
16/94	Infotainment Control Module (ICM), XC90	31/95	Ground connection, left MacPherson strut tower, XC90
16/105	Audio control module (AUD), XC90	31/96	Ground connection, right MacPherson strut tower
16/106	Control module, CD player (MP2), XC90	31/98	Ground connection, upper windshield member, XC90
16/107	Control module, MD player (MP1), XC90	31/100	Ground connection, engine ignition coils, 8-cyl.
16/108	Multimedia module (MMM), XC90	31/120	Ground connection, cargo compartment
16/110	Antenna control module (ATM), XC90	53/no.	Junction point
16/145	Satellite radio receiver	54/1B	Connector
16/149	MP3 player	54/57.1	Connector
17/13	Data link connector, XC90	16X/1	Connector, original car interface
17/17	Auxiliary start connection XC90	16X/45	Connector, original car interface
18/4	Contact reel, XC90	16X/57	Connector, original car interface, V70
20/3-8	Spark plug with ignition coil, XC90	16X/58	Connector, original car interface, V70
20/3-8	Spark plug with ignition coil, 8-cyl.	A1	Connecting rail to 15/31
20/12-13	Spark plug with ignition coil, 8-cyl.	C1-C6	Connecting rail to 15/31
20/14	Condenser, 8-cyl.		
20/22-26	Glow plug, XC90		
27/3	Left-hand Camera Module (LCM)		
27/4	Right-hand Camera Module (RCM)		
31/2	Ground connection, left MacPherson strut tower		
31/6	Ground connection, A-pillar left side, XC90		
31/10	Ground connection, A-pillar right side, XC90		